



# Universal PET Holder

...for simple connection of bottle necks and closures



The PET bottle finish fixture is a means for pressure testing closures on finishes of existing PET bottles if a preform isn't available for that purpose. It is designed for use inside the safety tank of the Steinfurth Closure Tester V4. It is made entirely of stainless steel and other water-resistant materials.

## BENEFITS:

- Wide range of standard adapters inclusive
- Easy change between bottle finishes
- Flexible usage in different Steinfurth testers
- Easy vacuum and pressure test on closures  
Quick connection to pressure source

## OPERATION:

The universal PET holder system, consisting of a set of bottle adapters and pairs of half rings, allows the use with a large variety of bottle finishes. The system fits also to the PET bottle finish fixture for vacuum tests and the Steinfurth OPT test bottle. The system is designed to withstand internal pressures up to 16 bar / 232 psi

## TECHNICAL DATA:

Max. pressure                    16 bar / 232 psi

Available bottle finish adapter (in mm):

26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36,  
37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47,  
48, other on request